

# Shock Guard TGZ Series

## Features

TGZ Series can be used as a simple layout release type protection device or an ON-OFF clutch.

### Release type

After tripping due to overload, the input side freely rotates. Even a high-speed shaft can be operated worry-free.

### Resetting by external force

After the Shock Guard has been stopped, remove the cause of overload. Then give load to the axial direction manually or with external force.

### ON-OFF function

The rotation (ON) or shut-off (OFF) functions are available arbitrarily. They can be used as an accurate mechanical type ON-OFF clutch.

### Easy torque adjustment

Just by turning the adjustment nut, trip torque can be easily set.

### Easy to see torque indicator

By using the revolution indicator and angle indicator, set torque can be monitored at any time.


### One position type

This uniquely assembled torque transmission element ball and pocket configuration only engages in one position.



## Operating Principles


### During normal operation (engagement)



Torque transmission is made by a drive ball which is pressurized and retained at the hub pocket and the driven flange.

The non-symmetric arrangement of the balls and pockets allows only one engagement position per one rotation, and there is no phase shift after tripping.


### During overload (trip)



When overloading (when OFF), a drive ball instantly pops out of its pocket, and the plate and a steel ball simultaneously move to the adjustment nut side.


A drive ball comes completely out of its pocket and a steel ball enters the hub outer circumference V-groove, and the pressure from the springs is not transferred to the plate. Therefore, a drive ball freely rotates without returning to the pocket.

# Construction



## Applications classified by use


### 1. Overload protection



As demonstrated in the diagram on the left, the TGZ Series can be installed with any motor shaft, reducer (variator) or other machines. When considering the layout, make sure to leave sufficient space to adjust torque and for resetting procedures. After removing the cause of overload, do not reset the machine while it is running.

⚠ If the Shock Guard is reset during rotation, the machine will suddenly run.

### 2. ON-OFF clutch



By using manual or mechanical external force (pneumatic, hydraulic, etc.), the plate can be moved, cutting off the input rotation (OFF) or transmitting it (ON). The necessary axial load for turning the machine ON or OFF is written in the table below.

Necessary shaft direction load when ON-OFF


Actuation Model No.	OFF → ON N   kgf	ON → OFF N   kgf	Amount of movement mm
<b>TGZ20-L</b>	49   5	245   25	4.1
<b>TGZ20-M</b>	88   9	431   44	
<b>TGZ20-H</b>	176   18	862   88	
<b>TGZ30-L</b>	98   10	470   48	4.7
<b>TGZ30-M</b>	235   24	1176   120	
<b>TGZ30-H</b>	470   48	2352   240	

Actuation Model No.	OFF → ON N   kgf	ON → OFF N   kgf	Amount of movement mm
<b>TGZ40-L</b>	157   16	774   79	5.9
<b>TGZ40-M</b>	421   43	2087   213	
<b>TGZ40-H</b>	833   85	4155   424	
<b>TGZ50-L</b>	451   46	2269   231	7
<b>TGZ50-M</b>	902   92	4518   461	
<b>TGZ50-H</b>	1382   141	6919   706	

Axial load fluctuates depending on the number of actuations and usage conditions. Set the load with margin.

## Transmissible Capacity/Dimensions

### Shock Guard (TGZ Series)



Unit : mm

Shock Guard Model No.	Set torque range N·m	Max. rpm r/min	Coil spring color X the number	Rough bore diameter	Min. bore diameter	Max. bore diameter	A	B	C	D	E	F	G min. point position	H	I amount of movement during trip	J	K PCD
<b>TGZ20-L</b>	2.4 to 8.3	1800	Yellowx3	8	10	20	74	73	1	8	6	13.5	0.8	11	4.1	96	86
<b>TGZ20-M</b>	4.1 to 16		Blue x3														
<b>TGZ20-H</b>	8.2 to 31		Blue x6														
<b>TGZ30-L</b>	5.9 to 21	1800	Yellowx4	12	14	30	83.5	82	1.5	8	6	14.5	1.1	11.5	4.7	118	106
<b>TGZ30-M</b>	20 to 52		Red x4														
<b>TGZ30-H</b>	39 to 108		Red x8														
<b>TGZ40-L</b>	25 to 93	1800	Blue x5	17	19	40	101	100	1	9	8	20	1.1	14	5.9	152	139
<b>TGZ40-M</b>	44 to 127		Red x5														
<b>TGZ40-H</b>	88 to 245		Red x10														
<b>TGZ50-L</b>	63 to 157	1800	Red x5	22	24	50	114.5	112	2.5	10	9	20.2	1.2	16	7	178	162
<b>TGZ50-M</b>	127 to 304		Red x10														
<b>TGZ50-H</b>	245 to 451		Greenx10														

Shock Guard Model No.	L h7	M	N	P	Q	R	S	T	U screw diameter X length	V	W	X screw size X length	Y screw size X length	* Mass kg	* Moment of inertia $\times 10^{-2} \text{kg} \cdot \text{m}^2$
<b>TGZ20-L</b>	72	35	24.5	32	57	70	88	4	M5 $\times$ 10	5	10	M5 $\times$ 10	M5 $\times$ 10	2.57	0.273
<b>TGZ20-M</b>															
<b>TGZ20-H</b>															
<b>TGZ30-L</b>	87	45	27.5	45	75	88	108	4	M6 $\times$ 12	6	10	M5 $\times$ 10	M6 $\times$ 10	4.17	0.695
<b>TGZ30-M</b>															
<b>TGZ30-H</b>															
<b>TGZ40-L</b>	114	65	32.5	65	103	119	141	6	M6 $\times$ 12	8	14	M8 $\times$ 10	M8 $\times$ 10	8.71	2.40
<b>TGZ40-M</b>															
<b>TGZ40-H</b>															
<b>TGZ50-L</b>	133	75	37	75	113	138	166	6	M8 $\times$ 16	9	14	M8 $\times$ 10	M8 $\times$ 10	13.7	5.30
<b>TGZ50-M</b>															
<b>TGZ50-H</b>															

\*1. All products are stock items.

\*2. Mass and moment of inertia are based on the bores' maximum diameters.



## Handling

### 1. Bore finishing (Shock Guard)

#### (1) Before finishing

The Shock Guard TGZ Series is shipped set at the minimum point (minimum torque value). Once received, confirm that the revolution indicator and angle indicator are set at zero.

#### (2) Disassembly

Loosen the setscrews, remove the adjustment nut and take out the coil springs, ball cage, plate and balls. Next, take out the shaft snap ring, and remove the bearing and driven flange. When disassembling, take care not to lose the ball B at s ball cage. Make sure the Shock Guard parts do not become dusty or dirty.

#### (3) Chucking

Chuck the hub flange's outside diameter and center the hub portion.

#### (4) Machining

##### ① Keyway specifications


Table 1 shows the maximum bore diameters for keyway specifications.

Table 1

Model No.	Max. bore diameter	Applicable standard
TGZ20	$\phi$ 20	parallel key
TGZ30	$\phi$ 30	
TGZ40	$\phi$ 40	New JIS
TGZ50	$\phi$ 50	Old JIS

##### ② Centering

Chuck the hub flange's outer edge and center the hub as shown in the figure on the right.




#### ③ Machining

The keyway should be machined directly below the setscrew tap at the hub flange section as shown below.

Table 2

Model No.	A
TGZ20	24.5
TGZ30	27.5
TGZ40	32.5
TGZ50	37.0

#### Set screw position



#### (5) Reassembly

After bore finishing is completed and when reassembling the Shock Guard, make sure to coat the drive balls, steel balls, pockets, and the V-groove with grease.

### 2. Bore finishing (Coupling type)

#### (1) Machining

##### ① Keyway specifications

Table 3 shows the maximum bore diameters on the coupling side. For the maximum bore diameters of the Shock Guard hub, refer to Table 1.

##### ② Centering


Chuck the coupling hub's outer edge and center the hub as shown in the below diagram. For the recommended positions of the coupling hub setscrew, refer to Table 4 (Length F).

Table 3

Model No.	Max. bore diameter	Applicable standard
TGZ20	$\phi$ 35	Parallel key
TGZ30	$\phi$ 47	
TGZ40	$\phi$ 58	New JIS
TGZ50	$\phi$ 63	Old JIS

Table 4

Model No.	Coupling model No.	Length F
TGZ20-C	L099-H	13.5
TGZ30-C	L110-H	20.5
TGZ40-C	L190-H	25.5
TGZ50-C	L225-H	25.5




### 3. Trip Torque setting


- (1) Shock Guard TGZs are all shipped with torque set at the minimum point (min. torque value). Confirm that the angle indicator and the No. of rotations indicator are set at zero. The No. of rotations indicator can be read at the end face of the adjustment nut. Refer to page 73 for more information.
- (2) From the "Tightening Amount-Torque Correlation Chart", find the adjustment nut tightening angle equivalent to the predetermined trip torque and tighten them. Set at 60° toward the determined tightening value, then install to the machine and conduct a trip test. Gradually tighten and set at optimum trip torque.
- (3) After setting torque, screw the lock screw to the adjustment nut. Refer to page 32 for lock screw tightening torque and precautions.
- (4) Do not turn the adjustment nut (bolt) more than the torque indicator's maximum value. Doing so will put it in a locked position, and there will be no leeway for the disk spring to bend.

\* Each product's trip torque does not always correspond with the value listed in the "Tightening Amount - Torque Correlation Chart", so use these values only as a rough guide.


TGZ 20(C)




TGZ 40(C)



TGZ 30(C)





TGZ 50(C)



### 4. Resetting

Match up one hole of the driven flange with the hub side's setscrew position. (This position is the pocket and drive ball's correct phase.)



Next, apply axial load to the plate to reset (refer to the following table). To determine whether the Shock Guard has completely reset, verify it using the measurements of the table below (displacement A).

Model No.	Axial load N   kgf	Amount of displacement A mm	B mm
<b>TGZ20-L</b>	49   5	4.1	13.5
<b>TGZ20-M</b>	88   9		
<b>TGZ20-H</b>	176   18		
<b>TGZ30-L</b>	98   10	4.7	14.5
<b>TGZ30-M</b>	235   24		
<b>TGZ30-H</b>	470   48		
<b>TGZ40-L</b>	157   16	5.9	20.0
<b>TGZ40-M</b>	421   43		
<b>TGZ40-H</b>	833   85		
<b>TGZ50-L</b>	451   46	7.0	18.2
<b>TGZ50-M</b>	902   92		
<b>TGZ50-H</b>	1382   141		

### Maintenance


Grease the drive ball and ball cage either once per year or every thousand trips.

## Special Specifications


### TGXZ Series

Non-backlash and complete release type. With its high-speed specifications (up to 1800r/min), it is ideal for when instant stop is not possible. Please contact TEM for more information.

#### ■ TGXZ Series only




#### ■ Coupling type




### TGZ Large Series

For the application of setting torque 451N · m and above, please contact TEM for more information.

#### ■ TGXZ Series only



#### ■ Coupling type



MEMO

Horizontal dotted lines for memo writing.

Shock Guard

TGZ Series